




PSP Go Top Cover Replacement

Top Cover Replacement.

Written By: Walter Galan



INTRODUCTION

Use this guide to replace your PSP Go's top cover.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Sony PSP Go Top Cover](#) (1)
-


Step 1 — Back Cover



- Unscrew the four Phillips screws on the back of the PSP Go.
- Rotate the PSP so you can see the top of the device.
- Unscrew the two Phillips screws next to the volume buttons.

Step 2



- Use a plastic opening tool around the perimeter of the back cover to loosen it on all sides.
 - Open the back cover by gently lifting the right side, and rotating it to the left side (as if you were opening a book).
-  Be careful not to rotate the back cover from the bottom, as you will break the plastic screw holes on top of the device.

Step 3 — Top Cover



- Pull the top cover upwards gently from its housing.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-19 06:08:32 AM.